

ALPHA[®] ROSIN FLUX 800 (RF-800)

NO CLEAN FLUX

DESCRIPTION

ALPHA RF-800 provides the broadest process window for a no-clean flux with less than 5% solids content. **ALPHA RF-800** is designed to provide excellent soldering results (low defects rates), even when the surfaces to be soldered (component leads and pads) are not highly solderable. **ALPHA RF-800** works particularly well with bare copper boards protected with organic or rosin/resin coatings and with tin-lead coated PCB's. **ALPHA RF-800** is used successfully in both tin-lead and lead-free applications.

ALPHA RF-800 is a very active, low solid, no-clean flux. It is formulated with a proprietary activator system. A small percentage of rosin is added for enhanced thermal stability. The activators are designed to provide the broadest operating window for a low solid, no-clean flux, while maintaining a high level of long-term electrical reliability. After wave soldering, **ALPHA RF-800** leaves a low level of non-tacky residue, which is easily penetrable in pin testing.

FEATURES & BENEFITS

- Highly active for excellent soldering and low defect rates.
- Low level of non-tacky residue to reduce interference with pin testing.
- Cleaning is not required which reduces operating costs.
- Reduces the surface tension between solder mask & solder to significantly reduce solder ball frequency.
- Meets Bellcore requirements for long-term electrical reliability.

APPLICATION GUIDELINES

 $\mathsf{PREPARATION}$ - In order to maintain consistent soldering performance and electrical reliability, it is important to begin the process with circuit boards and components that meet established requirements for solderability and ionic cleanliness. It is suggested that assemblers establish specifications on these items with their suppliers and that suppliers provide Certificates of Analysis with shipments and/or assemblers perform incoming inspection. A common specification for the ionic cleanliness of incoming boards and components is $5\mu g/in^2$ maximum, as measured by an Omegameter with heated solution.

Care should be taken in handling the circuit boards throughout the process. Boards should always be held at the edges. The use of clean, lint-free gloves is also recommended. When switching from one flux to another, the use of a new foam stone is recommended (for foam fluxing).

Conveyors, fingers and pallets should be cleaned. **ALPHA SM-110** Solvent Cleaner has been found to be very useful for these cleaning applications. When foam fluxing, do not use hot fixtures or pallets. Hot fixtures/pallets will deteriorate the foam head.

FLUX APPLICATION – **ALPHA RF-800** is formulated to be applied by foam, wave or spray methods. When foam fluxing, the foam fluxer should be supplied with compressed air which is free of oil and water.



ALPHA® ROSIN FLUX 800 (RF-800) NO CLEAN FLUX

Keep the flux tank full at all times. The flux level should be maintained 1 inch to 1-1/2 inches above the top of the stone. Adjust the air pressure to produce the optimum foam height with a fine, uniform foam head.

A uniform coating of flux is essential to successful soldering. When using the foam or wave method of application, an air knife is recommended after the fluxing operation. An air knife will help ensure that the flux is uniformly distributed across the board and will remove the excess flux. When spray fluxing, the uniformity of the coating can be visually checked by running a piece of cardboard over the spray fluxer or by processing a board-sized piece of tempered glass through the spray and then through the preheat section.

OPERATING PARAMETER	SAC305/SACX0307	63Sn/37Pb			
Amount of Flux Applied	Single Wave: 1000-1200 μg/in ² of solids Dual Wave: 1100-1500 μg/in ² of solids	Foam: 1,000 - 2,000 μg/in ² of solids Spray: 750 - 1,500 μg/in ² of solids			
When foam fluxing	When foam fluxing				
Foam Stone Pore Size	20 -50 μm	20 -50 μm			
Distance that top of stone is submerged below	1 - 1½ inches (25 - 40 mm)	1 - 1½ inches (25 - 40 mm)			
Foam Fluxer Chimney Opening	3/8 - 1/2 inch (10-13 mm)	3/8 - 1/2 inch (10-13 mm)			
When foam fluxing, use an Air Knif	fe				
Air Knife Hole Diameter	1 - 1.5 mm	1 - 1.5			
Distance Between Holes	4 - 5 mm	4 - 5			
Distance from Fluxer to Air Knife	4 - 6 inches (10-15 cm)	4 - 6 inches (10-15 cm)			
Air Knife Angle Back toward Fluxer from Perpendicular	3° - 5°	3° - 5°			
Topside Preheat Temperature	190° - 247°F (85° - 120°C)	190°F – 230°F (85°C - 110°C)			
Bottomside Preheat Temperature	about 65°F (35°C) higher than topside	about 65°F (35°C) higher than topside			
Maximum Ramp Rate of Topside Temperature (to avoid component damage)	2°C/second (3.5°F/second) maximum	2°C/second (3.5°F/second) maximum			
Conveyor Angle	5°-8° (6° most common)	5°-8° (6° most common)			
Conveyor Speed	3 – 6 feet/minute (.9 – 1.8 meters/minute)	4 - 6 feet/minute (1.2 - 1.8 meters/minute)			
Contact Time in the Solder	1.5 - 3.5 seconds	1.5 - 3.5 seconds			
(includes ChipWave and Primary	(2-21/2 seconds most common)	(2-21/2 seconds most common)			
Solder Pot Temperature	490° - 520°F (250° - 270°C)	460° – 500°F (235°-260°C)			
These are general guidelines which have pro and circuit boards, your optimal settings ma					

and circuit boards, your optimal settings may be different. In order to optimize your process, it is recommended to perform a designed experiment, optimizing the most important variables (amount of flux applied, conveyor speed, preheat temperatures, and solder pot temperature and board orientation).



ALPHA® ROSIN FLUX 800 (RF-800) NO CLEAN FLUX

FLUX SOLIDS CONTROL - If foam, wave, or rotary drum, spray fluxing, the flux solids will need to be controlled via thinner addition to replace evaporative losses of the flux solvent. As with any flux with less than 5% solids content, specific gravity is not an effective measurement for assessing and controlling the solids content. Monitoring and controlled to between 17 and 19. Alpha's Flux Solids Control Kit #3, a digital titrator, is suggested. Request Alpha's Technical Bulletin SM-458 for details on the kit and titration procedure. When operating the foam fluxer continuously, the acid number should be checked every two to four hours. Over time, debris and contaminants will accumulate in recirculating type flux applicators. For consistent soldering performance, dispose of spent flux every 40 hours of operation. After emptying the flux, the reservoir and foam stone should be thoroughly cleaned with flux thinner.

RESIDUE REMOVAL – **ALPHA RF-800** is a no-clean flux and the residues are designed to be left on the board. However, if desired, **ALPHA RF-800** residues can be removed with **ALPHA 2110** Saponifier.

TOUCH-UP/REWORK - Use of the Cleanline Write Flux Applicator with **ALPHA NR205** flux and **ALPHA Telecore** Series cored solder wire is recommended for hand soldering applications.

SAFETY

Consult the SDS for all safety information. The most recent version of the SDS is available from alphaassembly.com. Inhalation of the flux solvent and volitalized activator fumes which are generated at soldering temperatures may cause headaches, dizziness and nausea. Suitable fume extraction equipment should be used to remove the flux from the work area. An exhaust at the exit end of the wave solder machine may also be needed to completely capture the fumes. Observe precautions during handling and use. Suitable protective clothing should be worn to prevent the material from coming in contact with skin and eyes.

ALPHA RF-800 flux contains a highly flammable solvent with a flashpoint of 56°F (13°C). The flux must not be used near open flames or near non-flameproof electrical equipment.

TECHNICAL DATA

Parameters	Parameters Typical Values Parameters/Test Method		Typical Values	
Appearance	Pale, yellow liquid	pH (5% aqueous solution)	3.4	
Solids Content, %wt/wt	4.1	Recommended Thinner	ALPHA 425	
Acid Number (mg KOH/g)	18.0 ± 1.0	Shelf Life (from Date of Mfg.)	540 days	
Specific Gravity @ 25°C (77°F)	0.794 ± 0.003	Container Size Availability	1, 5, and 55 Gallons; 20 Liters	
Pounds Per Gallon	6.6	Bellcore TR-NWT-000078, Issue 3 Compliant	Yes	
Flash Point (T.C.C.)	56°F (13°C)	IPC J-STD-004 Designation	ROL0	



ALPHA[®] ROSIN FLUX 800 (RF-800) NO CLEAN FLUX

CORROSION & ELECTRICAL TESTING – SAC305 ALLOY

CORROSION TESTING

Corrosion Testing	Requirement	Results			
Silver Chromate Paper Test	No Detection of Halide	PASS			
Copper Mirror Test	No Complete Removal of Copper	PASS			
IPC Copper Corrosion Test	No evidence of corrosion	No Corrosion (Type L)			

IPC J-STD-004A SURFACE INSULATION RESISTANCE

Test	Conditions	Requirements	Results
"Comb-Down" Un-cleaned	85℃/85% RH, 7 days	> 1.0 x 10 ⁸ Ω	1.1 x 10 ¹⁰ Ω
"Comb-Up" Un-cleaned	85℃/85% RH, 7 days	> 1.0 x 10 ⁸ Ω	9.8 x 10 ⁹ Ω
Control Boards	85℃/85% RH, 7 days	> 1.0 x 10 ⁹ Ω	1.1 x 10 ¹⁰ Ω
IPC Test Condition (per J-STD-004A): -50V, measurement @ 100V/IPC B-24 board (0.4 mm lines, 0.5 mm spacing).			

BELLCORE SURFACE INSULATION RESISTANCE

Test	Conditions	Requirements	Results
"Comb-Down" Un-cleaned	35℃/85% RH, 4 days	> 1.0 x 10 ¹¹ Ω	7.0 x 10 ¹³ Ω
"Comb-Up" Un-cleaned	35℃/85% RH, 4 days	> 1.0 x 10 ¹¹ Ω	4.6 x 10 ¹³ Ω
Control Boards	35℃/85% RH, 4 days	> 2.0 x 10 ¹¹ Ω	3.1 x 10 ¹³ Ω
Bellcore Test Condition (per TR-NWT-000078, Issue 3: 48 Volts, measurement @ 100V/25 mil lines/50 mil spacing.			

BELLCORE ELECTROCHEMICAL MIGRATION RESISTANCE

Test	SIR (Initial)	SIR (Final)	Requirement	Result	Visual Result
"Comb-Up" Un-cleaned	3.0 x 10 ⁹	3.8 x 10 ⁹	SIR (Initial)/SIR (Final) < 10	PASS	PASS
"Comb-Down" Un-cleaned	2.8 x 10 ⁹	4.0 x 10 ⁹	SIR (Initial)/SIR (Final) < 10	PASS	PASS
Bellcore Test Condition (per TR-NWT-000078, Issue 3): 85 °C/85%RH/500 Hours/10V, measurement @ 100V/IPC B-25 B Pattern (12.5 mil lines, 12.5 mil spacing)					

TECHNICAL BULLETIN



ALPHA® ROSIN FLUX 800 (RF-800)

NO CLEAN FLUX

CONTACT INFORMATION

To confirm this is the most recent issue, please contact Alpha Assembly Solutions

AlphaAssembly.com North America Europe Asia 300 Atrium Drive Unit 2, Genesis Business Park 8/F., Paul Y. Centre Somerset, NJ 08873, USA Albert Drive 51 Hung To Road 800.367.5460 Woking, Surrey, GU21 5RW, UK Kwun Tong, Kowloon, Hong 01483.758400 Kong 852.3190.3100

Also read carefully warning and safety information on the Safety Data Sheet. This data sheet contains technical information required for safe and economical operation of this product. READ IT THOROUGHLY PRIOR TO PRODUCT USE. Emergency directory assistance Chemtrec 1 - 800 - 424 - 9300.

DISCLAIMER: All statements, technical information and recommendations contained herein are based on tests we believe to be reliable, but the accuracy or completeness thereof is not guaranteed. No statement or recommendation shall constitute a representation unless set forth in an agreement signed by officers of seller and manufacturer. NO WARRANTY OR MERCHANTABILITY OR WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE IS MADE. The following warranty is made in lieu of such warranties and all other warranties, express, implied, or statutory. Products are warranted to be free from defects in material and workmanship at the time sold. The sole obligation of seller and manufacturer under this warranty shall be to replace any product defective at the time sold. Under no circumstances shall manufacturer or seller be liable for any loss, damage or expense, direct or consequential, arising out of the inability to use the product. Notwithstanding the foregoing, if products are supplied in response to a customer request that specifies operating parameters beyond those stated above, or if products are used under conditions exceeding said parameters, the customer by acceptance or use thereof assumes all risk of product failure and of all direct, indirect and consequential damages that may result from use of the products under conditions, and agrees to exonerate, indemnify and hold harmless MacDermid Incorporated thereform. No suggestion for product use nor anything contained herein shall be construed as a recommendation to use any product in infringement of any patent rights, and seller and manufacturer assume no responsibility or liability for any such infringement.

® Registered Trademark of MacDermid Performance Solutions. ™ Trademark of MacDermid Performance Solutions. © Platform Specialty Products Corporation and its subsidiaries 2016.